

ESTATES AND FACILITIES

MANOR PARK HEATING

You have the ability to adjust the temperature in your room (to a maximum of 22°C) by using either the thermostat on your wall or the valve on your radiator.

If you live in Manor Park Block A through to Block F you will have a radiator with a thermostatic valve, as per the picture below. To turn up the heating on your radiator, the valves are operated by a coin – turn the valve, using the coin towards the thick blue line to reduce the temperature and towards the thinner blue line for more heat.



Blocks G, H, P, Q and R are electric and there will be a thermostat box on your wall, which will look either like this, or like this. Note that they are equipped with a motion sensor, which will turn off your heating, if it doesn't sense movement.



UNIVERSITY OF
SURREY